



DESIG	P	DRAWN BY	DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA
CHEC	KED ,	APPROVED	DRAWING NO. REV. A
	#	4	DSI 9199 SHEET 1 OF 4
DATE			TITLE SCALE
01.0	3.20		UTILITY POD LATCH/PROP CHANGE NTS
Α		01.03.20	NEW ISSUE

DART SERVICE INSTRUCTION

TO AMEND INSTALLATION DRAWING D350-602 REV. D (REF. CANADIAN STC: SH93-97, FAA STC: SR01144NY) AND INSTALLATION INSTRUCTIONS IIN-D407-627 REV. B (REF. CANADIAN STC: SH98-57)

THE PARTS LIST OF IIN-D407-627 REV. B AND D350-602 REV. D SHOULD BE AMENDED AS FOLLOWS:

REPLACE:

Qty	Part Number	Description
3	D2204-9	LATCH
1	D2527-041	PROP ASSEMBLY
2	D2528-1	BACKER PLATE
2	D2528-3	BACKER PLATE
12	AN4-5A	BOLT
12	AN960JD416	WASHER
2	MS20600AD4W4	RIVET (OR CR9163-4-4)
12	MS21042L4	NUT (OR MS21042-4)

WITH:

Qty	Part Number	Description
Х	DSI 9199-011	LATCH/PROP CHANGE KIT
	D0000 4	BRANCI ATOLI
3 2	D2998-1	DRAW LATCH
	D2998-3	DRAW LATCH
3	D2999-1	SPACER BLOCK
3	D3000-041	KEEPER ASSEMBLY
2	D3000-043	KEEPER ASSEMBLY
1	D3002-1	DOUBLER
1	D3007-041	PROP ASSEMBLY
1	*D3007-1	STRUT
1	*D2012-107	CLEVIS
2	*D2022-101	SPACER
1	*AN4-10A	BOLT
1	*AN960JD416	WASHER
1	*MS21042L4	NUT (OR MS21042-4)
1	*D3008-1	SUPPORT BRACKET
1	*SL69-BS	CLIP
1	*5/16-18	UNC LOCK NUT
1	*AN960JD516	WASHER
	ANEOCOCOOD7	CODEIM
2	AN526C632R7	SCREW
4	AN526C832R8	SCREW
2	AN526C832R14	SCREW
5	AN526C832R16	SCREW
2	AN526C832R18	SCREW
8	AN526C1032R8	SCREW
2	AN526C1032R9	SCREW
2	AN960JD6	WASHER
13	AN960JD8	WASHER
9	AN960JD10	WASHER
2	AN960JD10L	WASHER
2	MS21042L06	NUT (OR MS21042-06)
13	MS21042L08	NUT (OR MS21042-08)
10	MS21042L3	NUT (OR MS21042-3)

^{*} INCLUDED IN D3007-041 PROP ASSEMBLY




DESIGN	DRAWN BY	DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA		
CHECKED	APPROVED	DRAWING NO. DSI 9199 SHEET	REV. A 2 OF 4	
DATE		TITLE	SCALE	
01.03.20		UTILITY POD LATCH/PROP CHANGE	1:30	


IF REPLACING D2204-9 LATCHES WITH D2999-1 AND D2999-3 LATCHES, REPLACE AS FOLLOWS:

- REMOVE D2204-9 LATCHES AND D2527-041 PROP ASSEMBLY. PLUG HOLES WITH 5-MINUTE EPOXY OR HARDWARE IF DESIRED.
- 2) INSTALL D2998-1/-3 LATCHES AND D3007-041 PROP ASSEMBLY USING THE HARDWARE SHOWN ON PAGES 2 TO 4 OF THIS DOCUMENT. TRANSFER DRILL HOLES TO POD FROM LATCH BRACKETS PROVIDED AND SEAL THE EDGES OF ALL HOLES WITH CYANOACRYLATE GLUE (CRAZY GLUE). TRANSFER DRILL AS FOLLOWS: AN526C632 → DRILL Ø0.141

AN526C832 → DRILL Ø0.172 AN526C1032 → DRILL Ø0.191

3) NOTE: ALL DIMENSIONS ARE GIVEN IN INCHES






Copyright @ 2001 by DART AEROSPACE LTD

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.





DESIGN (DRAWN BY	DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA		
CHECKED	APPROVED A	DRAWING NO.	REV. A	
W T	#	DSI 9199 SHEET	3 OF 4	
DATE		TITLE	SCALE	
01.03.20		UTILITY POD LATCH/PROP CHANGE	1:2	





Copyright © 2001 by DART AEROSPACE LTD

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.



DESIGN	DRAWN BY	DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA	
CHECKED	APPROVED /	DRAWING NO.	REV. A
91	#	DSI 9199 SHEET	4 OF 4
DATE		TITLE	SCALE
01.03.20		UTILITY POD LATCH/PROP CHANGE	1:2





Copyright © 2001 by DART AEROSPACE LTD

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.